

RECON 264343 Cab Light Install

The dimensions for each of the five holes is $9/16''$ x $1\ 1/4''$ and the screw hole is centered and $11/16''$ from back edge of each hole.

The front edge of each hole is $7\ 3/8''$ from the windshield. Because the windshield dips down in the middle, the middle three cab lights will be a few inches forward of the two outside lights.

The outside holes are $3\ 1/4''$ from the side of the cab to the outer edge of the hole

The second cab light from the side of the truck cab is $18\ 1/4''$ from edge of the cab to the outer edge of the hole.

The middle cab light is $7''$ apart from the adjacent lights.



You will not need to cut the side out as shown in the picture, our cab lights will mount in a perfect rectangular hole.

