

# IRECON

Supplemental install instructions for  
part #26415X & 26416X

## *XTREME SCANNING LED TAILGATE LIGHTBARS*

First connect the flat four connector and white reverse light wire as stated in the included instruction sheet then follow the supplemental instructions below:

The remaining **RED** wire needs to be connected to a constant 'hot' 12V power source such as the wire coming off either your Ignition or Accessory Terminal where your ignition key goes into your vehicles steering column. Most late model vehicles have ample space under the dashboard on the driver side where you can access these two ignition/accessory wires. The **RED** wire **MUST** be connected to one of these two wires otherwise the Xtreme light bar will not function properly.

**If you have any questions, feel free to contact us:  
info@GoRECON.com - www.GoRECON.com**