

RECON

Get Lit!

Install Guide for 2641XHP

The 2641XHP is used as an extension of the wiring for RECON part 26416XHP to allow it to function properly on newer Ford F150 and Superduty trucks. Simply plug it into the harness off of the tailgate bar and then connect the other end to the 4 way trailer plug on the truck. The red wire of the 2641XHP needs to be connected to a constant or accessory hot source on the truck. If you would like to hardwire the harness, then please refer to the wire diagram on the standard tailgate bar install guide.

Please contact us at 877.377.3266 or at info@gorecon.com with any additional questions

©2019 www.gorecon.com